



# SCHEMATICS


CUSTOMER SERVICE  
**1-800-446-1071**

Germany / Gas / Summit (Late 2010-2017)

[VIEW ALL](#)

MODEL #: 7371075 DESCRIPTION: SUMMIT E-670 LP BLK 30MB (2011) (CENTRAL EUROPE)

[Print Schematic](#)



01.11

SEQ	DESCRIPTION	PART#
A	Assembly guide, Summit 670 '11, GROUP 3	56645
A	Literature kit, Summit 670 '11, GROUP 3	56749
B	Hardware kit, Summit '11	84280
B	Hardware for frame/rear panel, Genesis '11	62776
B	Hardware for IR cover	70392

B	Hardware kit for bottom panel	67762
B	Hardware for burner tubes, Genesis/Summit '07	88210
B	Hardware for bezels/control panel	88208
B	Hardware for side burner table, Genesis	67765
B	Hardware for cookbox, Summit '10	60600
B	Hinge rod and clip for side burner lid, Genesis '07	67764
B	Hardware for tank blocker	88063
B	Tank glide buttons and hardware, export	88066
B	Manifold hardware, Summit '07	88067
B	Rotisserie hardware for tuckaway rotisserie, w/forks, '10	84116
B	Hardware kit for control panel, Summit '11	88231
B	Hardware for bulkhead, Summit '07	88212
1	Hinge pin/cotter pin kit	70302
2	Weber logo with hardware, '07	70304
2	Lid assembly, Summit 600 '11, black	70107
3	Thermometer, Genesis/Summit, export '14	70014
4	Bezel for Genesis/Summit, '07	67717
5	Handle with bezels/spacers/hardware, Summit 600 series	70369
5	Spacers for handle, black, quantity 2	70368
5	Hardware pack for handle	65908
6	Weber Handle Light, Genesis/Summit '16	65612
7	Rotisserie motor, Type F, 220-240 V, '15	65577
8	Bracket assembly for Tuck-Away rotisserie, '12	70016
8	Plastic latch w/spring	70888
9	Warming rack, Summit 600 '07	70190
10	Rod-style grate, SS, 11.8", qty. 1	70372
11	Flavorizer bars, SS, set of 4	70375
12	Burner tube, Summit, export, quantity 1	70308
13	Hardware for table assembly, Genesis 300 series, '11	62773

13	LHS tuck-away table assembly, Summit EU, SS	66290
14	Tool hook for LHS table, Summit '07	70312
15	Manifold assembly 30mb, Summit E/S 670	79180
15	Manifold hardware, Summit '07	88067
16	Momentary light switch, Summit '11	70189
16	Wiring harness, Summit 670	70882
17	Control panel w/artwork, Summit 670 '10, export	84495
17	Hardware kit for control panel, Summit '11	88231
18	Hardware for bezels/control panel	88208
18	Small bezel w/fasteners, Summit 470/670	70883
19	IR burner control knob, Summit export	70383
20	Control knob assembly, Summit LTD '08, export	30134702
20	Lighted control knob assembly, '12, export	91540
21	Hardware for bezels/control panel	88208
21	Bezel for main burners with hardware	70318
22	Sear knob assembly, Summit '11, export	30134602
23	Battery pack head	70879
23	Battery pack housing	70880
24	Heat shield/water baffle, Summit 670	70874
24	Hardware for burner tubes, Genesis/Summit '07	88210
25	Aluminum drip pans - package of 10	6417
26	Grease tray, Summit 600 '11, SS	70113
27	Catch pan kit	70379
28	Hardware for tank blocker	88063
28	Tank blocker, Summit 600 series	70324
29	LHS door assembly, Summit 600, black	70027
30	Door handles with hardware	70327
31	RHS door assembly, Summit 600, black - export	70030
32	Adjustable door hinge	70332

32	LHS frame assembly, Summit '11, US	70981
33	Bottom panel, Summit Platinum 6 burner NG, '10	91316
33	Hardware kit for bottom panel	67762
34	Hardware for IR cover	70392
34	IR Burner wire wrap, Summit '14	43291
34	Rain cover for IR burner, Summit 660 built-in	85650
35	IR burner with bracket	70389
35	LP Orifice for IR burner, with nut, 30mb	70384
36	Cover box for IR burner	70338
37	Thermocouple with electrode and wire	70390
37	Thermocouple nut	20201822
38	Thermocouple nut	20201822
38	Thermocouple with electrode and wire	70390
39	Gas line for IR burner, 64"	70398
40	Screws for rotisserie forks, qty 4	70380
40	Rotisserie hardware for tuckaway rotisserie, w/forks, '10	84116
40	Rotisserie shaft w/handle, Summit E/S 650/670/660 - export	80685
40	Handle for rotisserie shaft, Summit '11, export	89062
41	Rod-style grate, SS, 8.1", qty. 1	70373
42	Smoker box assembly	70381
43	Chipper grate, Summit '07 smoker	70187
44	Burner tube, Summit w/smoker, export, quantity 1	70310
45	Sear burner assembly, Summit 6 burner - export	70041
46	Side burner ring	91173
46	Ignition assembly for side burner	91174
46	Side burner cap, Summit '03	91175
46	Trivet, SS, Summit	91176
46	Rubber lid bumper for side burner (Qty 1)	81252
46	LP side burner assembly, 29 mb, Summit export	70393

46	Hardware for side burner table, Genesis	67765
46	Control knob for side burner, gray.	30130201
47	Silicone bumpers, quantity 4	70339
47	Cookbox, Summit 670 '13	64847
47	Hardware for cookbox, Summit '10	60600
47	Flavor bar brackets Summit cookbox 6 burner	64849
48	Hardware for bulkhead, Summit '07	88212
48	LP bulkhead assembly, Summit export	70346
49	Corrugated gas line, main, Summit 600 series	70309
51	Hinge rod and clip for side burner lid, Genesis '07	67764
51	Side burner lid, Summit/Genesis	70121
52	Hardware for table assembly, Genesis 300 series, '11	62773
52	Side burner table assembly, SS	70053
52	Hardware for side burner table, Summit '11	88230
53	RHS tool holder with hardware	70349
54	Transfer line for side burner	70371
55	Hardware for frame/rear panel, Genesis '11	62776
55	Frame connector and hardware, Summit 6 burner	70351
56	Rear panel, LP Summit 600 series	70354
57	Adjustable door hinge	70332
57	RHS frame assembly, Summit NG '11, EXP	70193
58	Tank hanger assembly w/bracket, Genesis - export	70063
59	Tank hanger assembly w/bracket, Genesis - export	70063
60	Tank glide buttons and hardware, export	88066
61	Match holder	81544
62	Fixed caster with insert (qty 1)	70359
63	Locking caster with insert (qty 1)	70360